



INSTALLATION INSTRUCTIONS AND SAFETY INFORMATION

FOR THE VIKING L-3 GATE OPERATOR



CLASS I, CLASS II, CLASS III,
AND CLASS IV


**Residential and Commercial
Vehicular Slide Gate Operator**






The L-3™ gate operator has the capacity to operate slide gates up to 1600 lbs. and 60 ft. in length at 100% duty cycle under extreme conditions. This efficient operator provides a solution for high traffic commercial slide gate applications. The Viking L-3™ gate operator offers efficiency and technology combined in a single package.

THE VIKING L-3™ SLIDE GATE OPERATOR




PARTS DIAGRAM:




| Item | Description | Part No. |
|------|-------------------------------------|----------|
| 1 | Chassis | VNXL3CH |
| 2 | Chassis Battery Bracket | VNXCHBRK |
| 3 | Gear Box | VNXL3GB |
| 4 | Motor | VNXL3MO |
| 5 | Electronic Positioning Sensor (EPS) | VNXL3EPS |
| 6 | 40B17 Sprocket | VAL3SP17 |
| 7 | Idler Pulley | DSIP10 |
| 8 | Idler Bushing (w/hardware) | DSIB10 |
| 9 | Battery Switch | DUMRS10 |
| 10 | Alarm | DUAL10 |
| 11 | Alarm Reset Switch | VNXDUARS |
| 12 | Manual Release Switch | DUMRS10 |
| 13 | Control Board | VFLEXPCB |
| 14 | Battery | DUBA12 |
| 15 | Access Door | VNXAD |
| 16 | Key and Lock | VNXSLCL |
| 17 | Operator Cover | VNXCV |
| 18 | Modular Power Box Assembly | VNXMPB |
| 19 | EMI Board | VNXDUEMI |
| 20 | Toroid Transformer - 15 amp | DUTT15 |
| 21 | 120V Receptacle | DUOLI20 |
| 22 | 120VAC Power Switch | DUMRS10 |
| 23 | EMI Fuse Holder & Harness | VNXEFHH |
| 24 | Fuse - 4 amp | VNXF4A |
| 25 | Fuse - 15 amp | VNXF15A |
| 26 | 25' #40 Chain Kit, Nicle Coated | VAL3CKN |
| 27 | Motor Harness | VNXL3MH |
| 28 | Power Harness | VNXL3PH |
| 29 | Brush Kit | VAMBK |
| 30 | Loop Rack | VA-LR |

Overall Dimensions




Weight - 115 lbs.

OPERATOR REFERENCES:



1. OPERATOR COVER
2. COVER LOCK
3. ACCESS DOOR
external access to the Manual Release Switch and Alarm Reset Button
4. BATTERY BACKUP SYSTEM
5. VFLEX CONTROL BOARD
6. BATTERY SWITCH
disconnects batteries from the charging circuit during troubleshooting
7. EPS (ELECTRONIC POSITIONING SENSOR)
sensor for the digital limits
8. MOTOR
9. LOOP RACK
for convenient loop detector installation
10. GEARBOX
11. MANUAL RELEASE/MOTOR Switch
discontinues power to the motor and allows for manual operation of gate
12. ALARM RESET BUTTON
resets the operators alarm
13. POST MOUNTING U-BOLT HOLES
for optional post mount installation
14. J-BOX
high voltage power supply connection
15. EMI FUSE
main power supply protection
16. MODULAR POWER BOX
removable; provides a convenient solution for optional low voltage installations

CONTROL BOARD REFERENCES:



1. POWER HARNESS CONNECTOR provides power to the control board. pg 18-19
2. "OPEN LEFT" & "OPEN RIGHT" connect the motor harness here. pg 20
3. LIMIT SETUP BUTTONS sets limit positions. pg 21-22
4. FEATURE ACTIVATION TRIM POTS activate and set features. pg 24
5. "EPS1" CONNECTOR available for future developments
6. "EPS2" CONNECTOR monitors the limit positions.
7. EMI BOARD CONNECTOR monitors the high voltage power supply.
8. "CHECK MOTOR" Status LED indicates motor power status. pg 35
9. "LOW BATTERY" Status LED indicates battery power status. pg 35
10. "POWER" Status LED control board power status. pg 35
11. "MAGNETIC LOCK" Status LED status of this on-board relay. pg 41
12. "MAGNETIC LOCK" Terminal Block connect electric locks here. pg 32
13. INPUT STATUS LEDS indicates input status. pg 34
14. ACCESS CONTROL TERMINAL BLOCKS accessory connections. pg 27-30, 40-42
15. "Master/Slave" Terminal Block wired master/slave connection. pg 22
16. CONTROL BOARD MOUNTING HOLES secures and grounds the control board.
17. "Siren" Terminal Block Vikings UL Sired is connected here.
18. "BRAKE" Terminal Block used for solar applications & in-motion warning devices. pg 19, 25
19. ON-BOARD 3 BUTTON STATION controls the gate during set up.
20. FEATURE ACTIVATION PIN HEADERS active features by placing a jumper onto the pin headers. pg 25
21. "DIAGNOSE" Button allows you to navigate through the
22. "DIAGNOSE" LED informs that errors have been detected and available on LCD Display. pg 36-39
23. LCD DIAGNOSTICS DISPLAY provides error messages, diagnostics and operator status information. pg 36-39
24. VIKING ADD-ON CONNECTIONS connections for Viking Blue, Viking Cell, Viking WIFI and VIKING RF. pg 44
25. "FAIL SAFE/SECURE" Jumper power failure option. pg 25
26. MOTOR FUSE
27. CHARGER FUSE
28. HEAT SINK secures the control board and dissipates heat.

TABLE OF CONTENTS:

| | |
|---|--------------|
| PARTS DIAGRAM/PARTS LIST | 2 |
| OPERATOR REFERENCES | 3 |
| CONTROL BOARD REFERENCES | 4 |
| IMPORTANT SAFETY INFORMATION | 6-12 |
| Important Safety Instructions..... | 6 |
| Important Installation Instructions..... | 7 |
| Maintenance..... | 8 |
| General Safety Precautions..... | 8-9 |
| Operator Classification..... | 9 |
| Photo Beam (non-contact sensor) Installation..... | 10 |
| Edge Sensor (contact sensor) Installation..... | 11 |
| Manual Release..... | 11 |
| Audible Alarm Reset Installation..... | 12 |
| Warning Placard Installation..... | 12 |
| IMPORTANT INSTALLATION INFORMATION | 13 |
| Specifications..... | 13 |
| GATE OPERATOR INSTALLATION | 14-17 |
| Concrete Pad Option..... | 14 |
| Post Mounting Option..... | 15 |
| Operator Positioning..... | 16-17 |
| ELECTRICAL INSTALLATION | 18-19 |
| High Voltage Supply Option..... | 18 |
| Low Voltage Supply Option..... | 19 |
| Solar Supply Option..... | 19 |
| LIMITS SETUP | 20-21 |
| MASTER/SLAVE SET UP | 22-23 |
| Two Wire Communication..... | 22 |
| Wireless Communication (Bluetooth) Option..... | 23 |
| CONTROL BOARD SETUP | 24-26 |
| Initial Settings..... | 24-25 |
| Obstruction Detection Sensor (Primary Entrapment Protection)..... | 26 |
| ACCESSORY CONNECTIONS | 27-32 |
| Re-Open Photo Beam (Vehicular Safety)..... | 27 |
| Radio Receiver (Typical)..... | 28 |
| Anti-Tail Gate, Open Commands, Guard Station..... | 29 |
| Viking Loop Rack..... | 30 |
| Guidelines for Loop Installations..... | 31 |
| Magnetic Lock, Lock Solenoid..... | 32 |
| Barrier Arm (B-12) Synchronization Option..... | 33 |
| TROUBLESHOOTING | 34-39 |
| LED References..... | 34-35 |
| LCD Display References..... | 36-38 |
| Solutions..... | 39 |
| APPENDIX A, B & C | 40-43 |
| VIKING EXPANSION PRODUCTS | 44 |

IMPORTANT SAFETY INFORMATION

⚠ WARNING! Not Following these instructions may cause severe injury or death.

IMPORTANT SAFETY INSTRUCTIONS

⚠ WARNING! To reduce the risk of severe injury or death.

1. READ AND FOLLOW ALL INSTRUCTIONS.
2. Never let children operate or play with gate controls. Keep the remote away from children.
3. Always keep people and objects away from the gate. **NO ONE SHOULD CROSS THE PATH OF THE MOVING GATE.**
4. Test the gate operator monthly. The gate **MUST** reverse on contact with a rigid object or when an object activates the non-contact sensors. After adjusting the force or the limit travel, retest the gate operator. Failure to adjust and retest the gate operator properly can increase the risk of injury or death.
5. Use the manual release only when the gate is not moving.
6. **KEEP GATES PROPERLY MAINTAINED.** Read the owners manual. Have a qualified service person make repairs to gate hardware.
7. The entrance is for vehicles only. Pedestrians must use a separate entrance.
8. **Every gate operator installation MUST have secondary protection devices against entrapment, such as edge sensors and photo beams more in particular in places where the risk of entrapment is more likely to occur.**
9. SAVE THESE INSTRUCTIONS.

IMPORTANT INSTALLATION INSTRUCTIONS

1. Install the gate operator only when:
 - a. The operator is appropriate for the construction of the gate and usage Class of the gate (refer to page 5),
 - b. All openings of a horizontal slide gate are guarded or screened from the bottom of the gate to a minimum of 4 feet (1.22 m) above the ground to prevent a 2-1/4 inch (57.2 mm) diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that the gate covers in the open position,
 - c. ALL EXPOSED PINCH POINTS ARE ELIMINATED OR GUARDED, AND
 - d. GUARDING IS SUPPLIED FOR EXPOSED ROLLERS.
2. The Operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. Locate the gate such that persons will not come into contact with the vehicular gate during the entire path of travel of the vehicular gate.
3. The gate must be installed in a location so that enough clearance is supplied between the gate and adjacent structures when opening and closing to reduce the risk of entrapment. Swinging gates shall not open in to the public access areas.
4. The gate must be properly installed and work freely in both directions prior to the installation of the gate operator. Do not over-tighten the operator clutch or pressure relief valve to compensate for a damaged gate.
5. The gate operator controls must be placed so that the user has full view of the gate area when the gate is moving **AND AWAY FROM THE GATE PATH PERIMETER.**

IMPORTANT SAFETY INFORMATION

 **WARNING! Not Following these instructions may cause severe injury or death.**

IMPORTANT INSTALLATION INSTRUCTIONS (Continued)

6. Controls intended for user activation must be located at least six feet (6') away from any moving part of the gate and where the user is prevented from reaching over, under, around or through the gate to operate the controls. Outdoor or easily accessible controls shall have a security feature to prevent unauthorized use.
7. The Stop and/or Reset button must be located in the line-of-sight of the gate. Activation of the reset control shall not cause the operator to start.
8. All warning signs and placards must be installed where visible in the area of the gate. A minimum of two placards shall be installed. A placard is to be installed in the area of each side of the gate and the gate be visible to persons located on the side of the gate on which the placard is installed.
9. **For gate operators using non-contact sensors (Photo Beams or like) in accordance with section 31.1.1 of the UL standard:**
 - a. The operator is appropriate for the construction of the gate and usage Class of the gate (refer to page 5),
 - b. Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle, trips the sensor while the gate is still moving, and
 - c. One or more non-contact sensors shall be located where the risk of entrapment or obstruction exists, such as the perimeter reachable by a moving gate or barrier (refer to page 6).
 - d. Use only Omron E3K-R10K4 photoelectric eye to comply with UL 325
10. **For a gate operator utilizing a contact sensor (Edge sensor or like) in accordance with section 31.1.1 of the UL 325 standard:**
 - a. One or more contact sensors shall be located where the risk of entrapment or obstruction exists, such as a the leading edge, trailing edge, and post mounted both inside and outside os a vehicular horizontal slide gate (refer to page 7).
 - b. One or more contact sensors shall be located at the bottom of a vehicular vertical lift gate.
 - c. One or more contact sensors shall be located at the pinch point of a vehicular vertical pivot gate.
 - d. A hardwired contact sensor shall be located and its wiring arranged so that the communication between the sensor and the gate operator is not subject to mechanical damage.
 - e. A wireless contact sensor such as one that transmits radio frequency (RF) signals to the gate operator for entrapment protection functions shall be located where the transmission of the signals are not obstructed or impeded by building structures, natural landscaping or similar obstructions. A wireless contact sensor shall function under the intended end-use conditions.
 - f. One or more contact sensors shall be located on the inside and outside leading edge of a swing gate. Additionally, if the bottom edge of a swing gate is grater than 6 inches (152 mm) above the ground at any point in its arc of travel, one or more contact sensors shall be located at the bottom edge (refer to page 7).
 - g. One or more contact sensors shall be located at the bottom edge of a vertical barrier (arm).
 - h. Only Use Miller Edge Model MGR20 or MGS20 edge sensor to comply with UL325

IMPORTANT SAFETY INFORMATION

 **WARNING! Not Following these instructions may cause severe injury or death.**

MAINTENANCE

Remove the Power Harness from the Control Board (refer to page 15)

- Clean and lubricate the turning pins and gate hinges using the recommended lubricant.
- Check that all mounting hardware of the gate operator is properly tighten.
- Ensure that the gate moves freely.
- Check for corroded parts and replace if necessary.
- Check the battery for the following:
 - Battery connections must be free of corrosion.
 - Battery voltage must be 26v DC (fully charged battery).

Reconnect the Power Harness for the Control Board (refer to page 15)

- Check and confirm the proper operation of all safety devices (photoelectric eye, edge sensors or like).
- Check and confirm the operation of all installed accessories.
- Check and confirm the operation of all special features such as the Intelligent Obstruction Sensor, Hold Open Timer (refer to page 22 to 28)
- Check and confirm the operation of the manual release (refer to page 7)
- Verify battery backup functionally by turning off the power source (120v AC and 220v AC). **DO NOT FORGET TO TURN ON THE POWER SOURCE AFTER VERIFICATION.**

GENERAL SAFETY PRECAUTIONS

The following precautions are an integral and essential part of the product and must be supplied to the user. Read them carefully as they contain important indications for the safe installation, use and maintenance.

- These instruction must be kept and forwarded to all possible future users of the system.
- This product must be used only for that which it has been expressly designed.
- Any other use is to be considered improper and therefore dangerous.
- The manufacturer cannot be held responsible for possible damage caused by improper, erroneous or unreasonable use.
- Avoid operating in the proximity of the hinges or moving mechanical parts.
- Do not enter the path of the moving gate while in motion.
- Do not obstruct the motion of the gate as this may cause a situation of danger.
- Do not allow children to play or stay within the the path of the moving gate.
- Keep remote control or any other control devices out of the reach of children, in order to avoid possible involuntary activation of the gate operator.
- In case of break down or malfunctioning of the product, disconnect from the main power source. Do not attempt to repair or intervene directly, contact only qualified personnel for repair.
- Failure to comply with the above may create a situation of danger.
- All cleaning, maintenance or repair work must be carried out by qualified personnel.
- In order to guarantee that the system works efficiently and correctly it is important to have the manufacturer's instructions on maintenance of the gate and operator carried out by qualified personnel.
- In particular, regular checks are recommended in order to verify that the safety devices are operating correctly.

All installation, maintenance and repair work must be documented and made available to the user.

IMPORTANT SAFETY INFORMATION

⚠ CAUTION: To Reduce the Risk of Fire or Injury to Persons:


- a. Use only the following type and size battery(ies): Yuasa NP7-12
- b. Do not dispose of the battery(ies) in fire. The cells may explode. Check with local codes for possible disposal instructions.
- c. Do not open or mutilate the battery(ies). Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed.
- d. Exercise care in handling batteries in order not to short the battery with conducting materials such as rings, bracelets and keys.
- e. Change the battery(ies) provided with or identified for use with this product only in accordance with the instructions and limitations specified in this manual.
- f. Observe proper polarity orientation between the battery(ies) and charging circuit.
- g. Do not mix batteries of different sizes or from different manufactures in this product (applies to products employing more than one user replaceable secondary battery).
- h. A battery-operated product employing a secondary battery supply intended to be charged within the product shall contain specific instructions concerning the proper method of charging.

UL325 Gate Operator Classification

GLOSSARY


RESIDENTIAL VEHICULAR GATE OPERATOR

CLASS I - A vehicular gate operator (or system) intended for use in a home of one-to four single family dwelling, or a garage or parking area associated therewith.




COMMERCIAL/GENERAL ACCESS VEHICULAR GATE OPERATOR

CLASS II - A vehicular gate operator (or system) intended for use in a commercial location or building such as a multi-family housing unit (five or more single family units), hotel, garages, retail store, or other building servicing the general public.




INDUSTRIAL/LIMITED ACCESS VEHICULAR GATE OPERATOR

CLASS III - A vehicular gate operator (or system) intended for use in an industrial location or building such as a factory or loading dock area or other locations not intended to service the general public.



RESTRICTED ACCESS VEHICULAR GATE OPERATOR

CLASS IV - A vehicular gate operator (or system) intended for use in a guarded industrial location or building such as an airport security area or other restricted access locations not servicing the general public, in which unauthorized access is prevented via supervision by security personnel.



Install the gate operator only when:

The operator is appropriate for the construction of the gate and the Usage Class of the gate.

IMPORTANT SAFETY INFORMATION



⚠ WARNING! Not Following these instructions may cause severe injury or death.

NOTE: This type on installation DOES NOT reverse the gate all the way back to its limits when the photo beam is obstructed. This installation is only to protect against entrapment and to comply with UL325.

Secondary Entrapment Protection

Photo Beam (non-contact sensor) Installation

- **Photo beams or like must be installed to reduce the risk of entrapment.**
- Use only Omron E3K-R10K4 photoelectric eye to comply with UL325
- Make the electrical connections of the photoelectric sensor as described here in this page.
- Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle, trips the sensor while the gate is still moving, and;
- One or more non-contact sensors shall be located where the risk of entrapment or obstruction exists, such as the perimeter reachable by a moving gate or barrier.



Consult the installation manual for the UL325 device (photo beam or like) for detail information about the usage, installation and maintenance.

IMPORTANT SAFETY INFORMATION


⚠ WARNING! Not Following these instructions may cause severe injury or death.

NOTE: This type on installation DOES NOT reverse the gate all the way back to its limits when the edge sensor is obstructed. This installation is only to protect against entrapment and to comply with UL325.

Secondary Entrapment Protection

Edge Sensor (non-contact sensor) Installation

- **Edge Sensors or like must be installed to reduce the risk of entrapment.**
- Use only Miller Edge 3-sided activation type MGR20 or MGS20 to comply with UL325
- One or more contact sensors shall be located on the inside and outside leading edge of a swing gate. Additionally, if the bottom edge of a swing gate is greater than 6 inches (152 mm) above the ground at any point in its arc of travel, one or more contact sensors shall be located on the bottom edge.
 1. A hardwired contact sensor shall be located and its wiring arranged so that the communication between the sensor and the gate operator is not subjected to mechanical damage.
 2. A wireless contact sensor such as one that transmits radio frequency (RF) signals to the gate operator for entrapment protection functions shall be located where the transmission of the signals are not obstructed or impeded by building structures, natural landscaping or similar obstruction. A wireless contact sensor shall function under the intended end-use conditions.




Manual Release

When manual operation is required:

1. Lift the Access Door, located on the front of the cover.
2. Press the Manual Release Switch to the "RELEASE" Position.

The gate can now be moved manually. To resume normal operation, press the switch to the "ENGAGE" position.




IMPORTANT SAFETY INFORMATION

⚠ WARNING! Not Following these instructions may cause severe injury or death.

Audible Alarm Reset Switch Installation


Manual Reset for the Audible Alarm

- UL325 standard requires an audible alarm to go off after two consecutive events detected by the primary entrapment protection of the gate operator (obstruction sensor).
- The audible alarm will continue to sound for 5 minutes or until a stop command gets actuated.
- The Stop command can be actuated in three different forms:
 1. Using the Built in Stop switch on the Control Box or;
 2. Using an External Stop button within the sight of the gate, away from moving parts of the gate and out of reach of children.
 - a. Controls intended for user activation must be located at least six feet (6') away from any moving part of the gate and where the user is prevented from reaching over, under, around or through the gate to operate the controls. Outdoor or easily accessible controls shall have a security feature to prevent unauthorized use.
 - b. The Stop and/or Reset button must be located in the line-of-sight of the gate. Activation of the reset control shall not cause the operator to start.
 3. Using the Reset Button on the operator that is externally accessible from the covers Access Door.



Warning Placard Installation


- All Warning Placards must be installed where visible in the area of the gate.
- A minimum of two placards shall be installed.
- A placard is to be installed in the area of each side of the gate and be visible.



IMPORTANT INSTALLATION INFORMATION

⚠ CAUTION: To Reduce the Risk of Fire or Injury to Persons:

⚠ WARNING: For use with gates at a maximum 1600 lbs. in weight or 60 ft. in length.






DO NOT allow pedestrian use of this gate



DO NOT install the gate operator to lift gates

Locate Control Buttons:

1. Within sight of the gate,
2. At a minimum height of 5 feet so small children are not able to reach it; and
3. At least 6 feet away from all moving parts of the gate.



Specifications

| | |
|------------------------|---|
| Maximum Gate Length: | 60 ft. |
| Maximum Gate Weight: | 1600 lb. |
| Operating Temperature: | -20°F (-28°C) to 158°F (70°C) |
| Power Requirements: | 115v or 230v AC (4 amp) Single Phase (50 Hz / 60 Hz) |


GATE OPERATOR INSTALLATION

Concrete Pad Option

1. Follow the local building code to determine the required depth of the concrete pad.
2. Pad measurements recommended by Viking Access Systems are at least 24" long, 18" wide and 24" deep to ensure the stable operation of the operator, and a minimum of 4" above level grade to avoid any flooding of the machinery.
3. Provide a sufficient number of conduit pathways for all low power accessories such as loop detector leads, maglock, non-contact sensors, contact sensors, safety and other commands. Also provide conduit for the power supply to the operator.

⚠ DO NOT run low voltage and high voltage wiring in the same conduit.

⚠ Provide at least 12" separation between low and high voltage conduits.



GATE OPERATOR INSTALLATION



Post Mounting Option

TIP: The operator is equipped for post mount applications and is **ready for installation**. You will only need to supply the posts and u-bolts.

1. Consult the local building codes for the depth and concrete requirements.
2. Maximum 3.00" OD pipe.
3. Provide a sufficient number of conduit pathways for all low power accessories such as loop detector leads, maglock, non-contact sensors, contact sensors, safety and other commands. Also provide conduit for the power supply to the operator.

⚠ DO NOT run low voltage and high voltage wiring in the same conduit.

⚠ Provide at least 12" separation between low and high voltage conduits.



GATE OPERATOR INSTALLATION

Operator Positioning

⚠ IMPORTANT: All openings of a horizontal slide gate are guarded or screened from the bottom of the gate to a minimum of 4 feet (1.22 m) above the ground to prevent a 2-1/2 inch (57.2 mm) diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that the gate covers in the open position.






Figure A
Plan of Front Installation



Detail of Rear Install Chain Route

Figure B
Plan of Rear Installation


GATE OPERATOR INSTALLATION

⚠ TECHNICAL TIP: Before starting the installation procedure;

- Open and close the gate manually, making sure there is sufficient space between the gate and adjacent walls.
- Check that the wheels are turning freely on the track and there are no restrictions while pushing the gate to the open and closed positions.
- Confirm that there is adequate spacing for the guide rollers and that there are no restrictions throughout the travel of the gate.



STEP 1

Before securing the chassis to the concrete pad or posts, make sure the gate and operator is **LEVEL** and **PARALLEL**. Minimum distance between the operator and gate is 3".



STEP 2

Chain Installation: Before welding the provided chain brackets, make sure the chain will be in a straight line with, and at the same height as, the chain leaving the gate operator rollers.



ELECTRICAL INSTALLATION

High Voltage Supply Option

⚠ Caution: Always turn off power breakers when working with high voltage. DO NOT connect the “Power Harness” to the Control Board until the electrical installation is complete and ready for verification.

STEP 1

At the “Power Box”:

- Set the “Voltage Selector” according to the voltage supply.
- Turn the “120VAC Power” switch ON

STEP 2

⚠ Caution: SINGLE PHASE AC ONLY

At the “J-Box”:

- Connect the incoming power wires with the wire nuts provided; matching the color code.
- Turn the main breaker back ON.


STEP 3

- Verify that all three (3) Status LEDs are illuminated on the front panel of the Power Box.
- Turn the “Battery Switch” ON.

At the Control Board:

- Connect the Power Harness and verify that “POWER” LED is illuminated solid.


⚠ TECHNICAL TIP: If the “Power” LED is flashing or any of the 3 LEDs on the “Power Box” are not illuminated, refer to the Troubleshooting pages.



Tips for proper ground installation:

To minimize the effects caused by lightning, follow these guidelines.

- Use a ground rod to provide a ground reference.
- Consult your city code and be aware of under-ground services in the site of the gate operator to prevent inconveniences.
- Always use a single bonding point for grounding.
- All ground wires must be as short and as thick as possible.
- Prevent unnecessary turns or loops in all ground wires.




ELECTRICAL INSTALLATION

Low Voltage Supply Option

TIP: The operator is equipped with a **Modular Power Box** that can be relocated to provide power for low voltage installations. Supplies 24v AC to the operator.

⚠ Caution: Always turn off power breakers when working with high voltage. **DO NOT** connect the “Power Harness” to the Control Board until the electrical installation is complete and ready for verification.



Remove the “Power Box” from the operators chassis and relocate to the nearest high voltage source (115v or 230v single phase AC). Follow local codes or guidelines.



Solar Supply Option

Vikings Solar Package (**part # VA-SOCHP**) is an efficient and effective solution to powering the operator with solar energy. (See page 44 for package details)

⚠ Tip: For increased solar efficiency:
By activating the “Pre-Warning” feature, **(A)** the “Brake” terminals **(B)** will power to all non-essential controls beginning 3 seconds prior to gate movement and while the gate is moving. (page 25)



⚠ IMPORTANT: The number of cycles achieved daily is dependent on the average solar radiation of the geographic location and the power consumption of all accessories being used. Increased panel and battery capacities may be required. See Appendix C on page 43 for more important information regarding solar applications.

LIMITS SETUP


⚠ IMPORTANT: In the event of a complete power failure, including battery backup, the limits positions will have been cleared and will need to be reset by following the steps below.

STEP 1

Connect the Motor Harness to the:

“OPEN LEFT” connector if the gate opens to the left.

“OPEN RIGHT” connector if the gate opens to the right.



STEP 2

Move the gate at the desired open position then press the “Open Limit” button and hold it down until the LED stops flashing.

STEP 3




Move the gate at the desired close position then press the “Close Limit” button and hold it down until the LED stops flashing.

Tip: The gate can be moved electronically with the “Open”, “Stop” and “Close” buttons on the Control Board or manually by following the instructions on page 11.

LIMITS SETUP

⚠ NOTE:

1. The 1st cycle after the limit setup is the “Learn Cycles”. Allow a complete cycle to confirm your settings.
2. During the initial limit setup, the operator will run at half speed.



To Readjust the Open Limit:

1. Clear the current limit setting by holding down the “Open Limit” button until the LED is flashing.
2. Repeat STEP 2 on page 20 to set the limit.

To Readjust the Close Limit:

1. Clear the current limit setting by holding down the “Close Limit” button until the LED is flashing.
2. Repeat STEP 3 on page 20 to set the limit.

MASTER/SLAVE SETUP


Two Wire Communication

⚠ IMPORTANT: DO NOT run the Master/Slave communication cable in the same conduit or within 12" of 115 - 230v power supply cables.

⚠ Technical Tip: DO NOT set the "Timer" and/or "Overlap" features on both operators Control Boards. Only turn these features on at the Master Control Board.

CABLE REQUIREMENTS:

- 2 Conductor (wire)
- 18 AWG or better
- Shielded (overall foil)
- Drain Wire (non-insulated or bare wire)




Master Board

Slave Board

"MS1" ●-----● "MS1"

"MS2" ●-----● "MS2"



MASTER/SLAVE SETUP


Wireless Communication (Bluetooth) Option

⚠ **Technical Tip:** DO NOT set the “Timer” and/or “Overlap” features on both operators Control Boards. Only turn these features on at the Master Control Board.

REQUIRED ADD-ON:

1. Viking Blue - Wireless Master/Slave Kit
PART# VA-BLUE-MSKT

Connect one Bluetooth Module, provided with VA-BLUE-MSKT, to the “V-Blue” plug & play connection of each operators Control Board.



CONTROL BOARD SETUP

Initial Settings

“Timer” Hold Open Timer


Automatically closes the gate after the selected amount of time from 1-60 seconds.

Turning the dial to between “0” and “OFF” will disable this feature, requiring a close command to close the gate.

“Overlap” Overlap Delay

Delays the gate from closing for the selected amount of time from 1-6 seconds.

⚠ Typically not used on slide gates. For Master/Slave application, the control board that has this feature turned on is the master and will close first.



“ODS” Obstruction Detection Sensor

Sets the amount of force required to trip the inherent obstruction sensor.

See page 26 for more details about this feature,


“Speed” Motor Speed

Increases or decreases the speed of gate travel from 75% up to 150%.

CONTROL BOARD SETUP

Initial Settings

NOTE: Installing a jumper or jumper on the pins will activate the feature.



“Fail Safe/Secure”

During complete power failure, including battery power; determines the force required to manually move the gate.

- **Fail Safe Mode:**

By removing the wire-jumper plug from the “Fail Safe/Secure” connector:
The gate can move manually with a relatively low amount of force.

- **Fail Secure Mode:**

By inserting the wire-jumper plug into the “Fail Safe/Secure” connector:
The gate will not move manually.

“Auto Open” - Power Failure Option

Opens the gate automatically during power failure. Resumes normal operation when power is restored.

“Last Open” - Power Failure Option

Will open the gate automatically when batteries critically low.

“Pre-Warning” Initiates two options for an audio or visual warning 3 seconds prior to gate motion and will continue:

1. **Until gate reaches closed limit:**

“Magnetic Lock” terminals provide a contact between “COM” and “N.O”.

2. **While gate is moving:**

“Brake” terminals provide a 24v DC.

“Sync” Used only in conjunction with the Viking Barrier gate operator model B-12. Activating this feature allows for synchronized operation with the B-12 operator. See page 33.

“EXT” Activates the operators internal heater for application temperatures down to -20°F (-29°C).

⚠ IMPORTANT: Regardless of the power failure options chosen, the gate can be moved manually with a relatively low amount of force by following the steps for “Manual Release” as outlined at on page 13.

CONTROL BOARD SETUP

Obstruction Sensor (Primary Entrapment Protection)

⚠ IMPORTANT: The appropriate “ODS” setting is dependant upon the gate installation and construction. Set this feature accordingly. Additional Safety equipment should be used to reduce possible risk of injury or vehicle damage.

“ODS” Obstruction Detection Sensor

The Obstruction Sensor detects obstructions in the path of the traveling gate. The dial sets the amount of force required to activate the operators inherent obstruction detection.

Setting the dial to “0” will require the least amount of force to activate;

Setting the dial to “100” will require the maximum amount of force to activate.

UL325 standard requires an audio alarm to go off after two consecutive entrapment events sensed by the Inherent Entrapment Protection of the Gate Operator.


The audio alarm will sound for a period of 5 minutes or until the “Stop” Button is pressed (see page 8 for remote installation of a “Stop” Button).

When the Obstruction Sensor detects an obstruction it will:

1. Stop the gate’s movement and reverse it momentarily.
2. Bring the gate to a resting position.
3. Disable the Hold Open Timer feature until the Gate Operator receives a new command.


If second obstruction is detected before the gate reaches either limit it will:

1. Stop the gate’s movement.
2. Disable the Gate Operator.
3. Sound the UL Alarm
4. A STOP command must be provided to dis able the alarm and continue operation.



⚠ TECHNICAL TIP: The Status LED for the “ODS” will indicate the following when it has been triggered.


- A. Illuminated Solid:** Detected a sudden or abrupt increase in gate resistance.
- B. Flashing:** Detected an more subtle but sustained increase in gate resistance.



ACCESSORY CONNECTIONS

Re-Open Photo Beam (vehicular Safety)

NOTE: This type of photo-beam installation will stop then RE-OPENS the gate all the way to the open limit when the an beam is obstructed. Intended for vehicular safety ONLY. For the purpose of pedestrian entrapment, see pages 10-11.



Note regarding Photo Beam types:

Fail-Safe type - connect the “N.C.” terminal of the photo beam to any terminal labeled “GND” on the control board.

Typically, these are the reflective type photo beams.

Fail -Secure type - connect the “N.O.” terminal of the photo beam to any terminal labeled “GND” on the control board.

Typically, these are the transmitter/receiver type photo beams.

Check for proper operation:


The “Re-Open” LED will illuminate solid while the beam is obstructed and remain off when the beam is unobstructed.

⚠ TECHNICAL TIP: For more information regarding accessory connections to the control board and individual input terminal functions, refer to “Appendix (A)”, pages 40-41.

ACCESSORY CONNECTIONS

Radio Receiver (Typical)

⚠ IMPORTANT: The Hold Open “Timer” setting (page 24) effects how the gate will respond to the radio receiver command.



⚠ TECHNICAL TIP: For more information regarding accessory connections and terminal functions, refer to “Appendix (A)” on pages 40-41. See “Appendix (B)” on page 42 for connecting common radio receiver models.

The control board provides two modes of operation that a radio receiver can control the gate:

Open-Stop-Close

1. By having the radio receiver connected as illustrated and with the Hold Open Timer OFF (see page 28):

Every command of the radio transmitter will control the gate as follow:

- a. First command opens the gate,
- b. Second command stops the gate and
- c. Third command closes the gate
- d. Any subsequent commands will continue in the same order to control the gate.


This type of configuration is not recommended for a commercial installations.

Open Only

2. By having the radio receiver connected as illustrated and with the Hold Open Timer ON (see page 24):

Each command of the radio transmitter is **ALWAYS AN OPEN COMMAND** to the gate.


For maximum reception range:
Locate the radio antenna to the top of the gate column.



ACCESSORY CONNECTIONS

Anti-Tail Gate, Open Commands & Guard Station

⚠ TECHNICAL TIP: For more information regarding accessory connections and terminal functions, refer to “Appendix (A)” on pages 40-41.



Open Commands




“Exit”, “Fire” and “Strike” input terminals all provide an open command to the control board. Any device connected as shown will open the gate.

Guard Station

⚠ All three buttons must be a Normally Open “N.O.” type of switch, and can share the same common “C” connection to “GND”.

“ATG” Anti-Tailgate

This input will stop the gate when the vehicle triggers the sensor, then closes the gate when the vehicle leaves the sensor, preventing unauthorized vehicles from entry.




ACCESSORY CONNECTIONS

Viking Loop Rack

TIP: This operator may be equipped with a pre-wired **Loop Rack** that plug-in type loop detectors can be connected to. This provides a convenient alternative to the box type loop detectors that would need to be wired to the control board. Viking does not provide either type of loop detectors.

Loop Rack: Part # VA LR

Loop Rack Wiring Harness: Part # VA LRH



ACCESSORY CONNECTIONS

Guidelines for Loop Installation

1. Prevent sharp corners in the geometry of the loop sensor.
2. Install the appropriate number of turns for your loop geometry based on the loop perimeter. Use Table C (below) as a guide.
3. Use XLP (cross-linked-polyethylene) type of wire. This wire reduces the effects of moisture and other environmental events in altering the functionality of the vehicular loop detector.
4. Twist the lead wire at least 6 turns per foot.
5. Use BACKER-ROD to minimize damage to the loop detector wire prior to using the sealant.
6. Place the loop detector wire and adjust the sensitivity of the vehicular loop detector unit in a way to minimize the effects of the gate over the loop detector wire.

⚠ IMPORTANT! Some of the following parameters may affect the proper functionality of the vehicular loop detector.

Consult the manufacturer of the vehicular loop detector and/or loop wire.

- Gate size
- Number of turns in the loop sensor wire
- Distance of the loop sensor wire to the gate at either at the open or close position






Table C - Recommended Number of Turns

| Perimeter (ft.) | Number of Turns |
|-----------------|-----------------|
| 10 | 5 |
| 20 | 4 |
| 30-40 | 3 |
| 50-100 | 2 |




ACCESSORY CONNECTIONS


Magnetic Lock, Lock Solenoid

NOTE: Viking Access Systems does not provide these external gate lock devices and access control. These items can be purchased from your dealer or distributor.

Magnetic Lock




Lock Solenoid



Power

Do not use the 24v DC power supplied by the control board. An external power supply, or plug-in transformer, must be used for the magnetic lock or lock solenoid. Plug the transformer into the "120VAC" receptacle provided at the operators Power Box. This will prevent rapid drainage of the battery in the event of power failure.

The control boards "Magnetic Lock" relay is rated for 10A-250v AC.



SYNCHRONIZATION WITH B-12

Barrier Arm (B-12) Synchronization Option

NOTE: The Control Board provides a convenient solution for applications that require synchronized operation with the Viking Barrier Arm Operator model B-12.

This type of application opens and closes in the follow pattern:

1. Open Command is provided only to the Viking B-12 Barrier Arm Operator.
2. The Barrier Arm will delay to open until this Gate Operator reaches its Open Limit.
3. The Gate Operator will delay to close until the Barrier Arm reaches its Close Limit.

STEP 1 (Figure A & B)

Connect the Gate Operator to the Viking B-12 Barrier Arm Operator as illustrated.

STEP 2 (Figure A)

At the B-12 Barrier Arm Operator, connect the primary device that will be used as the OPEN input.

STEP 3 (Figure B)

On the Gate Operator Control Board, activate Sync Mode by placing a jumper on to the pin headers labeled "SYNC".

Figure A





Figure B



STEP 4 (Figure C & D)

Connect Viking B-12 Barrier Arm Operator to the Gate Operator as illustrated.

Figure C






Figure D



TROUBLESHOOTING

LED References

In addition to the LCD Display, the control board LEDs monitor the various circuits of the control board. Use the table below to identify the corresponding “TS Ref#” and refer to page 36-39 for further troubleshooting.



| # | LED | Status | Meaning | Page 39 TS Ref#(s) |
|---|-----------|--------|--|-----------------------|
| 1 | "Open" | OFF | Normal Condition. | 9, 10 |
| | | SOLID | Control board is receiving an input for a device connected to any of the following input terminals: Exit, Fire, Strike or Open (pages 29, 40). | |
| 2 | "STOP" | OFF | Normal Condition. | 9, 10 |
| | | SOLID | Control Board is receiving an input from a device connected to the Stop terminal (pages 29, 40). | |
| 3 | "Close" | OFF | Normal Condition. | 9, 10 |
| | | SOLID | Control Board is receiving an input from a device connected to the Close terminal (pages 29, 40). | |
| 4 | "C Loop" | OFF | Normal Condition. | 9, 10 |
| | | SOLID | Control Board is receiving an input from a device connected to the C Loop terminal (pages 29, 40). | |
| 5 | "ATG" | OFF | Normal Condition. | 9, 10 |
| | | SOLID | Control Board is receiving an input from a device connected to the ATG terminal (pages 29, 40). | |
| 6 | "Re-Open" | OFF | Normal Condition. | 9, 10 |
| | | SOLID | Control Board is receiving an input from a device connected to the Re-Open terminal (pages 27, 32, 40). | |
| 7 | "UL" | OFF | Normal Condition. | 9, 10 |
| | | SOLID | Control Board is receiving an input from a device connected to the UL terminal (pages 12-13, 40). | |
| 8 | "Radio" | OFF | Normal Condition. | 9, 10 |
| | | SOLID | Control Board is receiving an input from a device connected to the Radio terminal (pages 28, 40). | |

TROUBLESHOOTING

LED References


Page 39
TS Ref#(s)

| # | LED | Status | Meaning | |
|----|----------------------|----------|--|------------------------------|
| 9 | "AC VOLTAGE INPUT" | SOLID | Normal Condition. | 1 |
| | | OFF | Incoming power to Modular Power Box is not sufficient.(page 18). | |
| 10 | "PROTECTION WORKING" | SOLID | Normal Condition. | |
| | | OFF | EMI Board is damaged and circuit is not protected . Replace EMI Board. | |
| 11 | "AC VOLTAGE OUTPUT" | SOLID | Normal Condition. | 2 |
| | | OFF | There is no output voltage from the Modular Power Box. | |
| 12 | "120VAC POWER" | SOLID | Normal Condition for High Voltage installations. | 1 |
| | | OFF | High Voltage is not supplied to the Modular Power Box (page 18). | |
| 13 | "Open Limit" | OFF | Gate is not at the open limit position. | 6 |
| | | SOLID | Gate is at the open limit position. | |
| | | FLASHING | Open limit position has been erased or not set (page 20-21). | |
| 14 | "Close Limit" | OFF | Gate is not at the close limit position. | 6 |
| | | SOLID | Gate is at the close limit position. | |
| | | FLASHING | Close limit position has been erased or not set (page 20-21). | |
| 15 | "POWER" | SOLID | Normal Condition. | 1, 2 1, 2, 4, 5 |
| | | FLASHING | Operator is running on batteries only (pages 18-19). | |
| | | OFF | No power to control board. | |
| 16 | "Battery Low" | OFF | Normal Condition. | 1, 2 1, 2 |
| | | SOLID | Batteries are low. Check power supply to the operator. (pages 18-19). | |
| | | FLASHING | Batteries critically low. Check power supply to the operator. (pages 18-19). | |
| 17 | "Check Motor" | OFF | Normal Condition. | 7, 8 |
| | | SOLID | The control board is sending power to the motor but this circuit is not complete or closed. | |
| 18 | "Magnetic Lock" | SOLID | At Closed Limit and Magnetic Lock Relay state is Closed across "COM" & "N.O". (page 32). Gate should not be at closed limit. | |
| | | OFF | Not at Closed Limit and Magnetic Lock Relay state is Open across "COM" & "N.O". (page 32). Gate should be at closed limit | |
| 19 | "Timer" | OFF | The close timer is turned OFF or gate is not at the open limit if the timer is turned ON. (page 24). | 9, 10 |
| | | SOLID | Gate is at Open Limit, Timer is turned ON and counting down to close. (page 24). | |
| | | FLASHING | Gate is at Open Limit, Timer is turned ON but is not timing out due to a conflicting command. (page 24). | |
| 20 | "ODS" | OFF | Normal Condition. | 11, 13, 1, 2 11, 13, 1, 2 |
| | | SOLID | Obstruction has been detected. (page 26). | |
| | | FLASHING | Overload has been detected. (page 26). | |
| 21 | "Diagnose" | OFF | Normal Condition | |
| | | FLASHING | Errors have been detected; Check LCD Display for messages (pages 36-38). | |
| 22 | "Brake" | OFF | No voltage output on these terminals at the moment. | |
| | | SOLID | There is 24v DC output on these terminals at the moment. | |
| 23 | "Siren" | OFF | Normal Condition. | 11, 13, 1, 2 1, 2 |
| | | SOLID | Second consecutive obstruction has been detected. (page 28). | |
| | | FLASHING | Batteries are critically low. | |

TROUBLESHOOTING

LCD Display References

The control board is equipped with a LCD Display that provides operator information, current conditions, settings, diagnostics and error messages. Use the table below to identify the corresponding "TS Ref#" and refer to page 39 for further troubleshooting.



1. All messages will automatically scroll on the LCD Display. Error Messages will be displayed first.
2. The "Diagnose" LED will flash consecutively indicating how many Error Messages are available.
3. Press the Diagnose button to manually scroll through all of the Messages.

Page 39
TS Ref #s

| LCD MSG | Meaning |
|------------------|-----------------|
| VIKING ACCESS | Welcome Message |

| | |
|-------------|---------------------------------|
| MODEL L3 | Indicates the Model of the unit |
|-------------|---------------------------------|

System Status Messages

| | |
|-----------------|--------------------------------|
| GATE IS IDLE | Gate is stopped between limits |
|-----------------|--------------------------------|

| | |
|--------------------|-----------------|
| GATE IS OPENING | Gate is opening |
|--------------------|-----------------|

| | |
|--------------------|-----------------|
| GATE IS CLOSING | Gate is closing |
|--------------------|-----------------|

| | |
|-------------------|------------------------------------|
| GATE IS OPENED | Gate is at the limit open position |
|-------------------|------------------------------------|

| | |
|-------------------|-------------------------------------|
| GATE IS CLOSED | Gate is at the limit close position |
|-------------------|-------------------------------------|

| | | |
|---------------------|---|---------------|
| STOP BY OBSTRUCT | Gate stopped due to an obstruction sensor event | 11, 12, 13 |
|---------------------|---|---------------|

| | | |
|---------------------|--|--------|
| STOP BY OVERLOAD | Gate stopped due to an overload of the gate system | 11, 12 |
|---------------------|--|--------|

| | |
|-------------------|--------------------------------------|
| OVERLAP TIMING | Gate is waiting for the overlap time |
|-------------------|--------------------------------------|

| | |
|-------------------|---|
| HOLDING 25 SEC | Gate is at the limit open position and timing to close - The display shows the actual time left - prior to time-out |
|-------------------|---|

| | |
|------------|---|
| EPS2 OK | Electronic Positioning Sensor is functioning properly |
|------------|---|

LCD Display References

| LCD MSG | Meaning | |
|--------------------------------|--|---------|
| Multi meter displays | | |
| MOT AMP X.X A | This is the motor current amperage during operation | |
| MOT VOLT XX.X VDC | This is the actual motor voltage during operation | |
| AC VOLT XX.X VAC | This is the actual power supply AC Voltage form the toroid transformer | |
| CHARGE XX.X VDC | This is the charging voltage to the batteries | |
| BAT VOLT XX.X VDC | This is the charging voltage or the actual battery voltage if the charger is not available | |
| Board Settings Messages | | |
| EPS2 XX% ERR | Indicates that the Electronic Positioning Sensor (EPS) needs to be tuned. Error rate is displayed as a percentage | |
| SPEED XX% | Shows the percentage of speed set by the Speed adjustment on the control board. (pg. 24) | |
| OVERLAP X.X SEC | This feature is disable on a slider unit. Shows the number of seconds set by the Overlap Adjustment on the control board | |
| ODS SENS XX% | Shows the amount of force requires to trip the obstruction sensor. (pg. 26) | |
| TIMER XX SEC | Shows the time delay to hold the gate open at the limit open position, before starts closing the gate. (pg. 24) | |
| Error Messages | | |
| ERR AC LOW | Indicates the AC line is low in voltage - AC voltage is below 90 VAC (or 180 VAC for 220 VAC operation). | 1, 3, 4 |
| ERR AC HIGH | Indicates the AC line is high in voltage - AC voltage is above 130 VAC (or 260 VAC fro 220 VAC operation). | 1, 3 |
| ERR CHRG HIGH | Potential problem with the charging voltage from the control board. | 1, ? |
| ERR CHRG CHECK 4A | a) 4 Amp Fuse is blown b) or there is a problem with the control board | 15, ? |

TROUBLESHOOTING

LCD Display References

| LCD MSG | Meaning | Page 39 TS Ref #s |
|---------------------|--|----------------------|
| ERR BAT LOW | The battery is low | 1, 2, 3, 4 |
| ERR EPS2 WRONG | The EPS (Electronic Position Sensor) has one of the following conditions: a) The EPS is not properly adjusted b) The EPS has a potential connection problem c) The EPS has the wrong cable harness | X |
| ERR EPS2 MISSING | Missing EPS2 cable harness | 14, X |
| ERR FUSE 15 AMP | 15 AMP motor fuse is blown | 7, 11, 12 |
| ERR FUSE 20 AMP | 20 AMP motor fuse is blown (Only H-10) | 7, 11, 12 |
| ERR FUSE 30 AMP | 30 AMP motor fuse is blown (Only Q-7) | 7, 11, 12 |
| ERR EMI NO EMI | No EMI board detected | 15 |
| ERR EMI NO FUSE | 4 Amp main fuse is blown on Modular Power Box | 2 |
| ERR EMI NO AC | There is no AC line detected from the EMI Board in the Modular Power Box | 1, 4 |
| ERR EMI PROTECT | Lightning strike protection for the EMI Board in the Modular Power Box needs to be replaced | X |
| ERR SENS CURRENT | Motor Current Sensor need replacement | X |
| ERR SENS MOTOR | Motor is not detected | 7, 8 |

TROUBLESHOOTING

Solutions

Begin the troubleshooting process by referring to the error messages on the LCD Display and/or the Status LEDs on the control board. Use pages 34-38 to identify the Troubleshooting Reference # (TS Ref#) then reference the table below.


| TS Ref# | CHECK | Page Ref# |
|---------|---|---------------|
| 1 | Check that there high voltage power supplied to “J-Box” is within range. 100v-120v or 200v-240v | pg. 18 |
| 2 | Remove and check EMI Fuse for continuity. | pg. 3, 18 |
| 3 | Check that the “Voltage Selector”, on the Modular Power Box, is set according to the high voltage power supply. 115v AC or 230v AC | pg. 3, 18 |
| 4 | Check that the “120VAC” switch is turned ON | pg. 4, 18 |
| 5 | Check that the Power Harness is connected to the control board. | pg. 3, 18 |
| 6 | Set the limit position. | pg. 18-19 |
| 7 | Check Motor Fuse on the control board. | pg. 4 |
| 8 | Check that the Manual Release is turned to the “Engage” position. | pg. 3, 11 |
| 9 | Check the Status LEDs to determine if the control board is receiving an input from any external devices or if the “ODS” has been triggered. | pg. 26-30 |
| 10 | Remove the external devices from the control board to determine if the control board is responding to an input or problem with the external device or wiring. | pg. 27-32 |
| 11 | Check the gate, track and chain for any debris or cause for or resistance. Check the “ODS” setting on the control board. | pg. 8, 12, 26 |
| 12 | Check that the gate can be move manually with low resistance throughout its full length of travel. | pg. 8, 17 |
| 13 | Check the limit position. | pg. 20-21 |
| 14 | Check that the cable for the Electronic Positioning sensor is properly connected to the “EPS2” Connector on the control board. | pg. 4 |
| 15 | Check the EMI cable is properly connected to the “EMI” Connector on the control board. | pg. 4 |
| 16 | Check the LCD Display for Error Messages | pg. 36, 37 |
| ? | The control board may be damaged. Call Viking Tech Support for assistance. | |

Appendix (A)

Access Control Connections

Power Connections

The control board provides a 24v DC output to power external devices and controls. Alternatively, for devices that require a power supply other than 24v DC, the operators Power Box contains a convenient 120v AC receptacle to connect a plug-in transformer.



| | | |
|--------|---|---------------|
| “C” | = | Common |
| “N.O.” | = | Normally Open |

Terminals Connections and Input Functions:

| Viking Terminal | Function | Device Terminal |
|-----------------------------------|--|--|
| “+28v” | Positive | “+” |
| “GND” | Negative | “-” |
| “GND” | Common | “C” |
| “Radio” | | “N.O.” |
| | If “Timer” OFF: If “Timer” ON: | Open - Stop - Close Open gate / Stop while closing |
| “UL” (see pages 12 & 13) | | “N.O.” |
| | If Input is brief: If input is longer: | Stops gate then Reverses 12 inches Stops gate, does not reverse |
| “Re-Open” | | “N.O.” |
| | If stopped: If closing: | No function Stops then opens gate |
| “ATG” Anti-Tailgate | | “N.O.” |
| | Input is received: Input is released: | Stops gate if closing Closes gate to prevent tailgating |
| “C. Loop” | | “N.O.” |
| | If not at open limit: If at open limit: | No function Prevents gate from Closing |
| “Open”, “Exit”, “Fire” & “Strike” | | “N.O.” |
| | If stopped: If closing: | Opens gate Stops then Opens gate |
| “Stop” | | “N.O.” |
| | If traveling: | Stops gate |
| “Close” | | “N.O.” |
| | If stopped: If traveling: | Closes gate No function |

⚠ TECHNICAL TIP: Each input Terminal (i.e. Radio, Exit, Re-Open, UL) has a corresponding Status LED that when illuminated indicates an input is currently being provided to the terminal and the gate is responding accordingly. (See page 5 for LED References)

Relays In General


NOTE: Viking Access Systems does not provided the external safety devices and access controls. These items can be purchases from your dealer or distributor.

In General

In regards to the Viking control board, all external safety devices and access controls contain, and are, simple relays that provide an input to the Viking control board when the device is activated.

When these devices are activated, their internal relays create a contact ,or short, between the “C” and “N.O.” terminals This contact is what provides the command to the Viking control board.

⚠ TECHNICAL TIP: Viking uses the Normally Open “N.O.” contact from the device, excluding “fail-safe” type photo beams. In such instances, the Normally Closed “N.C.” will be used instead.




Glossary of Terms

- 1. Terminal:** Wire Connections.
- 2. Input Terminal:** On the Viking control board, the terminal which is labeled for a specific command (Re-Open, Exit, Radio, etc.). The N.O. contact from the access control device is to be connected to the Input Terminal.
- 3. Terminal Block:** On the Viking control board, a removable block containing multiple terminals.
- 4. Relay:** The component of an access control or safety device that provides an input or command to the Viking control board.
- 5. “C” Relay Common Terminal:** This is the relay terminal that make contact (a short) to the N.O. terminal when the device is activated. *Always wire this relay terminal to any “GND” terminal at the control board.*
- 6. “N.O.” Relay Normally Open Terminal:** The relay terminal that has an open contact to “C” while the relay is not activated, and a closed contact when the relay is activated. *Almost always wire this relay terminal to any “GND” terminal at the control board,*
- 7. “N.C.” Relay Normally Closed Terminal:** The relay terminal that has an open contact to “C” while the relay is not activated, and a closed contact when the relay is activated. *This terminal is rarely used.*
- 8. Relay Coil:** Contains the terminals that provide power at the relay.
- 9. “+” Relay Positive Terminal:** The positive power pole for the relay coil. *Always wire this relay terminal to any “+28v” terminal at the control board.*
- 10. “-” Relay Negative Terminal:** The negative power pole for the relay coil. *Always wire this relay terminal to any “GND” terminal at the control board.*


Appendix (B)

Common Radio Receivers - Connections


Multi-Code 1099




Multi-Code 1090



Liftmaster 312HM



Linear Delta 3 GRD



Solar Applications


NOTE: Viking recommends Solar Package (**part # VA-SOCHP**) for most general solar applications. Alternatively, individual and third party solar components can be used. The following are minimum system requirements and installation information.

Panels

- Voltage 24V DC
- Wattage 80W (minimum)

Cut the wires coming from the toroidal transformer.



Connect the solar panel cables to the power harness as shown.




Batteries & Fuse

- Voltage 24V
- Amp Hour 35Ah (minimum)
- Fuse 10A (minimum)

Replace the operators batteries with 35Ah or greater.



- ⚠ IMPORTANT:** The chart provided can be used as a guide to an idea of the number of cycles the gate will operate per day. The chart is for a single gate operator with just:
- One Radio Receiver
 - One low voltage, low current loop detector
 - One low voltage, low current photo beam



If more specific information is needed please consult with Viking Access Systems. For more information regarding solar energy refer to www.nrel.gov/solar

VIKING EXPANSION PRODUCTS



Viking Bluetooth Master/Slave kit Secure and reliable wireless Master/Slave communication using Vikings bluetooth technology
Part# VA-BLUE-MSKT



Viking Bluetooth Diagnostic Tool Provides wireless diagnostic information while within range of the control board.
Part# VA-BLUE



VIKING RF-Link Wireless Master/Slave communication using a robust bidirectional radio signal. **Part# VA-RFLINK**



VIKING WIFI provides remote access to the control board settings, programming, operator diagnostics, gate controls and gate status all from the convenience of a computer or any compatible handheld device.
Part# VA-WIFI



VIKING CELL Cellular access to the control board settings, programming, operator diagnostics, gate controls and gate status. Informs user when failure has occurs. **Part# VA-CELL**

For multiple monitored operators, an optional **GPS Locator** provides the operator coordinates. **Part#-VA-GPS**



VIKING SOLAR KIT The components included in this package are intended to provide sufficient power for general applications.
Part# VA-SOCHP

This Kit includes the following components:

- | | | |
|-----|-----------------------------|---|
| (2) | 12v 40w Solar Panels | Part# VA-SO40W (wired in series = 24v 80w) |
| (2) | 12v 35Ah batteries | Part# DUBA35 (wired in series = 24v 35Ah) |
| (1) | Solar Charger | Part# SOCHR10 |
| (1) | Solar Power Harness | Part# SOHAR |

⚠ NOTE: The number of cycles achieved from this kit are dependent upon the following and may require increased panel and battery capacities:

- Power consumption of all accessories being used
- Average solar radiation of geographic location

OUR CONTINUOUS COMMITMENT TO EXCELLENCE

Viking Access Systems is continuously working hard to identify and design products that will appeal to the industry and its needs. As technology continues to advance, we have developed a completely efficient and intelligent line of gate operators to meet the changing demands. These machines offer; full UL325 and UL991 compliance, soft-start and soft-stop, intelligent obstruction sensors, continuous operation (100% duty cycle) and extreme power efficiency. Innovative features include; adaptive and self-learning algorithms, redundancy design in both hardware and software to ensure operation and functionality, protection from lightning, short circuit and power surges, and our exclusive helical gearing offering the highest efficiency rating in the industry. Our entire product line is continually modified and improved based on the latest technology and our customer's valuable feedback. The results are products that offer accuracy, efficiency, reliability and performance, all in sleek, high-tech designs.

We pledge to continue establishing ourselves as the leader in high quality, innovative gate operators by developing "Next Level" technology. We are committed to providing safety and convenience with innovative solutions for every security gate need.



STANDARD FEATURES AND OPERATOR SPECIFICATIONS

- UL325 and UL991 Compliant by Underwriter Laboratories (UL) standards.
- Externally accessible Manual Release Switch
- Fail-Safe option sets the gate to automatically transfer to a fail-safe mode in the event of a power failure, allowing the gate to be pushed open without the use of special knowledge of the equipment
- Fail- Secure option sets the gate to electronically lock in the event of a power failure, allowing no manual movement without the use of the manual release
- Elegant design, appealing to any architectural project
- Plated and powder coated steel chassis
- Adjustable travel speed
- Up to 60' maximum gate opening
- 100% duty cycle
- Modular Power Supply Box for convenient low voltage installations
- 100 cycles of operation on backup battery (1000 lb. gate and 20' length)
- Intelligent speed control with smooth start and stop, self-adjust system
- Anti-Tailgating and Operation Pre-Warming features
- On-Board LCD Display provides diagnostics, operator status, settings and real-time volt and amp readings
- Intelligent obstruction detection with adjustable sensitivity
- Built-in climate control for cold weather applications
- Built-in protection against lightning strikes or similar electrical surges
- Inherent overload protection in the regulated power supply for external accessories with multiple devices of protection
- Modular connectors for easy access control installation
- Solar panel and low voltage wiring compatibility
- LED indicators display gate and operator status for easy troubleshooting

INSTALLATION DATE: _____

COMPANY / INSTALLER: _____

CONTACT: _____

SERIAL NUMBER(S): _____

ALL INSTALLATION, MAINTENANCE AND REPAIR WORK MUST BE DOCUMENTED AND MADE AVAILABLE TO THE USER.



VIKING ACCESS SYSTEMS

631 Wald Irvine, CA 92618

Phone 800.908.0884

Fax 949.753.1640

www.vikingaccess.com